

PF700 firmware upgrade process

To upgrade the firmware:

- If you update firmware, all settings of PF700 will be initialized. We recommend to backup the data before updating F/W.
 - Do NOT disconnect the power adapter during Firmware update.
1. Copy the file (**FWPF700.bin**) to the root dictionary of USB flash drive or SD/SDHC memory card. (If the version of your previous firmware is earlier than 1.2, please use SD/SDHC instead of USB flash drive.)
 2. Insert the USB flash drive or SD/SDHC memory card into the slot of PF700.
 3. Select Firmware upgrade from the Settings menu and press OK to start the firmware upgrade process. PF700 will automatically find the new firmware file.
 4. If PF700 finds that a newer version of firmware is available, a “Yes / No” selection message will be shown. Use LEFT or RIGHT to select “Yes” and press OK to perform the system upgrade. If you do not want to upgrade, press “No” to return to the Settings menu.
 5. After updating firmware success, please unplug the AC power cord.